

# Trennwandler M8742/22 Schalter Tabelle

Mod	Eingang	Ausgang	Schalter S1								Schalter S2						
			1/1	1/2	1/3	1/4	1/5	1/6	1/7	1/8	2/1	2/2	2/3	2/4	2/7	2/8	
1	0-1V	0-1V		X					X		X	X			X		
2	0-1V	0-10V		X					X		X		X		X		
3	0-1V	0-20mA	X						X	X	X			X	X		
4	0-1V	4-20mA	X			X	X			X				X	X		
5	0-10V	0-1V		X					X		X	X			X		X
6	0-10V	0-10V		X					X		X		X		X		X
7	0-10V	0-20mA	X						X	X	X			X	X		X
8	0-10V	4-20mA	X			X	X			X				X	X		X
9	0-20mA	0-1V		X					X		X	X			X	X	
10	0-20mA	0-10V		X					X		X		X		X	X	
11	0-20mA	0-20mA	X						X	X	X			X	X	X	
12	0-20mA	4-20mA	X			X	X			X				X	X	X	
13	4-20mA	0-1V		X	X						X	X					X
14	4-20mA	0-10V		X	X						X		X				X
15	4-20mA	0-20mA	X		X					X	X			X			X
16	4-20mA	4-20mA	X						X	X	X			X	X	X	
17																	