

## Systemanforderungen

PC mit Intel oder AMD Prozessor, Windows 2000/2003/XP/Vista®, freie USB Schnittstelle

## Allgemeine Hinweise

- Beenden Sie alle offenen Programme, bevor Sie mit der Installation beginnen.
- Für die Installation unter Windows 2000/2003/XP/Vista® werden Administratorrechte benötigt.

### Treiber für MJÖLNER Win installieren

[PC mit Windows XP]



Mjölner an eine freie USB Schnittstelle anschliessen. Windows erkennt die neue Hardware.

CD-ROM mit USB Treiber einlegen.


"Nein, diesmal nicht" auswählen  
Weiter >



"Software automatisch installieren" auswählen  
Weiter >



Fertig stellen



Im Geräte-Manager kann der neu installierte COM-Port angezeigt und gegebenenfalls geändert werden. Die COM-Port Nummer muss in der Mjölner-Win Software eingestellt werden. (Datei/Optionen).

### System requirements

PC with Intel or AMD Processor, Windows 2000/2003/XP/Vista®, unused USB Port

### General references

- Close all open programs, before beginning the installation.
- For installation under Windows NT/2000/2003/XP/Vista®, administrator rights are necessary.

### Software installation for Mostec programming adapter

[PC with Windows XP]



Plug "Mostec programming adapter" in an unused USB Port. Windows detects the new hardware.

Insert the CD-ROM with the USB driver.

Choose  
"No, not this time"  
Next >



Choose  
"Install the software  
automatically"  
Next >



Finish

