


Software Freischaltung VG-CSxxx

Vorgehen zur Software Freischaltung des VG-CSxxx

1. Schalten Sie das VG-CSxxx aus.
2. Drücken Sie gleichzeitig die Bedientasten **[F1]** und **[F2]**. Schalten Sie das Gerät ein und halten Sie die Tasten gedrückt, bis das Servicemenu erscheint.
3. Navigieren Sie mit den Tasten **[F1]** und **[F2]** durch das Servicemenu, bis zum Punkt **S7 Software enable code** und bestätigen Sie mit der **[ENT]** Taste.
4. Stellen Sie den erhaltenen Freischaltcode mit Hilfe der Tasten **[+]** / **[-]** ein, und bestätigen Sie mit **[ENT]**.
5. Verlassen Sie das Servicemenu mit Hilfe der **[ESC]** Taste, um in den Normalbetrieb zurückzukehren.
6. Falls die Freischaltung erfolgreich war, erscheint nun beim Einschalten des VG-CSxxx auf dem Display neu hinter der Seriennummer der Text ***PC**.

Frontplattenausschnitt:



Software unlocking VG-CSxxx

How to unlock the VG-CSxxx software

1. Switch the VG-CSxxx off.
2. Press the operating keys **[F1]** and **[F2]** simultaneously. Turn the VG-CSxxx on and keep the keys pressed until the service menu appears.
3. Use the buttons **[F1]** and **[F2]** to navigate through the menu, until the item **S7 Software enable code** appears and select it by pressing the **[ENT]** key.
4. Enter your personal software unlock code, using the keys **[+]** / **[-]** and press **[ENT]**.
5. Leave the service menu by pressing the **[ESC]** key.
6. If the unlocking process was successful, you will see the text ***PC** behind the serial number on the startup screen.

Front panel: